



**Purpose:** How to use the Terms of Agreement feature.

The Terms of Agreement page will be presented to the subscriber before the authentication process. The subscriber must agree to the terms in order to proceed with authentication.

**Note:** AAA must be enabled to use this feature.

Navigate to Subscriber Interface → Subscriber Messages, TOA

Enable Display of Terms of User Agreement Page and enter in your text in the text box. This is limited to 4000 characters and HTML characters can be used.

### Subscriber Page -- Terms of Agreement

Enable Display of Terms of User Agreement Page

#### Text for Terms of Agreement.

Total of 4000 characters max, including any HTML characters.

TERMS, CONDITIONS AND NOTICES

Lorem ipsum dolor sit amet, consectetur adipiscing elit. Donec ut pede eu metus feugiat pretium. Duis non ante. Nullam feugiat mauris sit amet est. Maecenas et ligula sed nisi fringilla ultricies. Vestibulum bibendum, ipsum sed vestibulum cursus, metus dui tempor justo, pulvinar ullamcorper tortor augue id quam. Vivamus cursus magna ut lectus. Sed ac justo vel ante gravida interdum. Suspendisse at augue. Duis urna. Donec auctor tincidunt leo.

Save

Clear Changes

Restore Defaults



# N O M A D I X

The user experience.



# N O M A D I X<sup>®</sup>

TERMS, CONDITIONS AND NOTICES Lorem ipsum dolor sit amet, consectetur adipiscing elit. Donec ut pede eu metus feugiat pretium. Duis non ante. Nullam feugiat mauris sit amet est. Maecenas et ligula sed nisi fringilla ultricies. Vestibulum bibendum, ipsum sed vestibulum cursus, metus dui tempor justo, pulvinar ullamcorper tortor augue id quam. Vivamus cursus magna ut lectus. Sed ac justo vel ante gravida interdum. Suspendisse at augue. Duis urna. Donec auctor tincidunt leo.

Login

Once the subscriber clicks on Login, they will proceed with the authentication process enabled on the NSE.